



Material data sheet – FlexLine

EOS Titanium TiCP grade 2

EOS Titanium TiCP grade 2 is commercially pure titanium alloy intended for processing on EOS DMLS™ machines.

This document provides information and data for parts built using EOS Titanium TiCP grade 2 powder (EOS art.-no. 9011-0036) on the following system setup:

- EOS DMLS™ machine: EOS M 290 400W
- EOS software: EOSPRINT v. 1.3 / HCS v. 2.3.29
- EOS parameter set: TiCP 30µm FlexLine

Description

The parts built with EOS Titanium TiCP grade 2 powder have chemical composition corresponding to ASTM F67. The parts have good strength-to-weight ratio, corrosion resistance and ductility. Parts built with EOS Titanium TiCP grade 2 powder can be machined, shot-peened and polished in as-built and heat treated states. Due to the layer-wise building method, the parts have a certain anisotropy.

Quality Assurance

The quality of the EOS Titanium TiCP grade 2 powder lots is ensured by the Quality Assurance procedures. The procedures include sampling (ASTM B215), PSD analysis (DIN ISO 13320), and chemical analyses. The results of the quality assurance tests are given in the lot specific Mill Test Certificates (MTC).



Material data sheet – FlexLine

Technical Data

Powder properties

Material composition	Element	Min	Max
	N	-	0.03
	C	-	0.08
	H	-	0.015
	Fe	-	0.30
	O	-	0.25
	Ti		bal.

Max. particle size

d50 [1]	38–45 μm
---------	---------------------

[1] Particle size distribution analysis according to DIN ISO 13320.

General process data

Layer thickness	30 μm
Volume rate [2]	5.0 mm ³ /s (18 cm ³ /h)

[2] The volume rate is a measure of build speed during laser exposure of the skin area. The total build speed depends on this volume rate and many other factors such as exposure parameters of contours, supports, up and downskin, recoating time, Home-In or LPM settings.

Physical and chemical properties of parts*

Part density [3]	min. 4.5 g/cm ³
Surface roughness after shot peening [4]	R _a < 10 μm ; R _z < 55 μm

[3] Weighing in air and water according to ISO 3369.

[4] Measurement according to ISO 4287. The numbers were measured at the horizontal (up-facing) and all vertical surfaces of test cubes. Due to the layerwise building the roughness strongly depends on the orientation of the surface, for example sloping and curved surfaces exhibit a stair-step effect.

Material data sheet – FlexLine

Tensile data at room temperature* [5, 6]

	As built	Heat treated [7]
Ultimate tensile strength, R _m	660 MPa	570 MPa
Yield strength, R _{p0.2}	560 MPa	445 MPa
Elongation at break, A	22 %	26 %
Reduction of area, Z	> 30 %	> 30 %

[5] The numbers are average values and are determined from samples with horizontal and vertical orientation.

[6] Tensile testing according to ISO 6892-1:2009 (B) Annex D, A14, proportional test pieces, diameter of the neck area 5 mm (0.2 inch), original gauge length 25 mm (1 inch).

[7] Heat treatment in 700 °C (± 10 °C) for 2 h (± 0.5 h) under argon.

Hardness* [8]

	Heat treated [7]
Hardness HV5	195

[8] Hardness measurement according to standard EN ISO 6507-1:2005 with load 5kgf (HV5).



Material data sheet – FlexLine

Abbreviations

min. minimum
max. maximum
wt. weight

*Part properties are provided for information purposes only and EOS makes no representation or warranty, and disclaims any liability, with respect to actual part properties achieved. Part properties are dependent on a variety of influencing factors and therefore, actual part properties achieved by the user may deviate from the information stated herein. This document does not on its own represent a sufficient basis for any part design, neither does it provide any agreement or guarantee about the specific properties of a material or part or the suitability of a material or a part for a specific application.

This powder has not been developed, tested or certified as a medical device according to Directive 93/42/EEC (MDD) or Regulation (EU) 2017/745 (MDR) and is not intended to be used as a medical device, in particular for the purposes specified in Art. 2 No. 1 MDR. Insofar as you intend to use the powder as raw material for the manufacture of pharmaceutical products or medical devices (e.g. as raw material which as a material must meet the requirements of Annex 1, Chapter II MDR), the responsibility and liability for all analyses, tests, evaluations, procedures, risk assessments, conformity assessments, approval and certification procedures as well as for all other official and regulatory measures required for this purpose shall lie solely with you both with regard to the pharmaceutical product and/or medical device manufactured by you and with regard to the properties, suitability, testing, evaluation, risk assessment, other requirements for use of the powder as raw material. This also applies to applications with food contact. In this respect, the limitations of liability pursuant to our General Terms and Conditions and the system sales or material contracts shall apply.

EOS[®], EOSINT[®], DMLS[®], DirectTool[®] and DirectPart[®] are registered trademarks of EOS GmbH.

© 2022 EOS GmbH Electro Optical Systems. All rights reserved.



Material data sheet – FlexLine

EOS Titanium TiCP

EOS Titanium TiCP is a titanium alloy powder intended for processing on EOS DMLS™ machines.

This document provides information and data for parts built using:

- EOS Titanium TiCP grade 2 powder (EOS art.-no. 9011-0036)
- EOS DMLS™ EOS M404 system
 - HSS blade (2200-4073)
 - Argon atmosphere
 - IPCM extra sieving module with 63 µm mesh (9044-0032) recommended
- EOSYSTEM:
 - EOSPRINT v 1.5 (Build9) or higher
 - HCS v 2.5.22 or higher
- EOS Parameter set: TiCP_030_FlexM404_100

Description

The parts built with EOS Titanium TiCP grade 2 powder have chemical composition corresponding to ASTM F67. The parts have good strength-to-weight ratio, corrosion resistance and ductility. Parts built with EOS Titanium TiCP grade 2 powder can be machined, shot-peened and polished in as-built and heat treated states. Due to the layer-wise building method, the parts have a certain anisotropy.

Quality Assurance

The quality of the EOS Titanium TiCP grade 2 powder lots is ensured by the Quality Assurance procedures. The procedures include sampling (ASTM B215), PSD analysis (DIN ISO 13320), and chemical analyses. The results of the quality assurance tests are given in the lot specific Mill Test Certificates (MTC).

Material data sheet – FlexLine

Technical Data

Powder properties

The chemical composition of the powder (wt-%):

Material composition			
	Element	Min	Max
	N	-	0.03
	C	-	0.08
	H	-	0.015
	Fe	-	0.30
	O	-	0.25
	Ti		Bal.

Max. particle size

> 63µm Max. 0.3 wt%

General process data

Layer thickness	30 µm
Volume rate [1]	5.0 mm ³ /s (18.0 cm ³ /h) 1.1 in ³ /h

[1] The volume rate is a measure of build speed during laser exposure of the skin area. The total build speed depends on this volume rate and many other factors such as exposure parameters of contours, supports, up and downskin, recoating time, Home-In or LPM settings.

Material data sheet – FlexLine

Physical and chemical properties of parts

Part density [2]	Approx. 4.5 g/cm ³ Approx. 0.163 lb/in ³
Min. wall thickness [3]	Approx. 0.3 – 0.4 mm Approx. 0.012 – 0.016 inch
Surface roughness after shot peening [4]	Ra < 10 µm; Rz < 55 µm Ra < 0.4 10 ⁻³ inch Rz < 2.2 10 ⁻³ inch

[2] Weighing in air and water according to ISO 3369.

[3] Mechanical stability is dependent on geometry (wall height etc.) and application.

[4] Measurement according to ISO 4287. Due to the layerwise building the roughness strongly depends on the orientation of the surface, for example sloping and curved surfaces exhibit a stair-step effect.

Tensile data at room temperature [5,6]

	Heat treated [7]	
	Horizontal	Vertical
Ultimate tensile strength, Rm	570 MPa	560 MPa
Yield strength, Rp0.2	430 MPa	430 MPa
Elongation at break A [8]	24 %	24 %
Reduction of area, Z	52 %	52 %

[5] Tensile testing according to ISO 6892-1 A14, proportional test pieces, diameter of the neck area 5 mm (0.2 inch), original gauge length 20 mm (0,79 inch).

[6] The numbers are average values determined from samples with horizontal and vertical orientation respectively

[7] Specimens were heat treated at 700 °C for 1.5 hours in argon inert atmosphere.

[8] Values are averaged and subject to variations depending on process conditions



Material data sheet – FlexLine

Abbreviations

Min.	Minimum
Max.	Maximum
Approx.	Approximately
Wt.	Weight

The quoted values refer to the use of this material with above specified type of EOS DMLS system, EOSYSTEM software version, parameter set and operation in compliance with parameter sheet and operating instructions. Part properties are measured with specified measurement methods using defined test geometries and procedures. Further details of the test procedures used by EOS are available on request. Any deviation from these standard settings may affect the measured properties.

The data correspond to EOS knowledge and experience at the time of publication and they are subject to change without notice as part of EOS' continuous development and improvement processes.

EOS does not warrant any properties or fitness for a specific purpose, unless explicitly agreed upon. This also applies regarding any rights of protection as well as laws and regulations.

EOS[®], EOSINT[®], DMLS[®], DirectTool[®] and DirectPart[®] are registered trademarks of EOS GmbH.

© 2017 EOS GmbH – Electro Optical Systems. All rights reserved.